

YOUR GUIDE TO THE OPTIMAL TENT GROUNDSHEET

Groundsheet and footprints must be perfectly aligned to the tent's base form; only then can they offer excellent protection from external factors. Here you'll find which sheet best suits which tent:

	3700 Zeitunterlage 250 x 220	3705 Zeitunterlage 230 x 160	3716 Zeitunterlage 250 x 155	3717 Zeitunterlage 250 x 185	3707 Apsidenunterlage 2	3708 Apsidenunterlage 3	3709 Apsidenunterlage Family
EXPERT		■*	■*				
2509 Kyrkja		■*	■*				
2600 Kiruna		■			■*		
2597 Okisba		■			■		
2548 Orbit 3		■*		■		■*	
2599 Polar 3		■*		■		■	
ALLROUND							
2401 Koli		■*	■*				
2550 Narvik 2		■*			■*		
2551 Narvik 3			■			■*	
2555 Grönland 2		■			■		
2556 Grönland 3			■			■	
2428 Grönland 3 Vent			■			■	
2451 Arctis 2.235 PU			■		■*		
2453 Arctis 3.235 PU				■		■*	
2455 Alaska 2.235 PU			■		■		
2457 Alaska 3.235 PU				■		■	
2430 Buffin 4	■*						■
2459 Alaska 4 PU	■						■
2584 Alaska 3 DLX	■*						■*
2585 Alaska Family DLX	■						■*
2446 Family Camp	■*						■*
2447 Family Camp Extension							■*
2444 Family Trek	■*						■*

Stand 02/2020

* not 100 % fitting

GROUNDSHEET

The ground sheet protects the base of the tent from damage caused by stones, branches etc., and fend off the rain and cold for longer. When making a purchase, always remember that the ground sheet should not be larger than the erected outer tent in order to avoid the "funnel effect".

PORCH GROUNDSHEETS

The ground sheet will make your vestibule a clean and dry space where you can store everything that isn't required in the inner tent.